Olympus Power Pvt.Ltd.

Technical Features



C	\cap	1	_	7	1
7	v	L	3	/	Z

	502512			
Туре	MPPT SOLAR CHARGE CONTROLLER			
Model	SO2572			
	<u>INPUT</u>			
Input Voltage Range	100V ~ 300V (Wide input voltage range)			
input voitage Kange	180V ~ 260V (Normal input voltage range)			
Nominal Input Voltage(s) Supported	220V AC , 50Hz			
Input connection type	Hard Wire			
BATTERY Full Load Runtime (minutes)	Depends on Load & Battery AH			
No of Battery	6			
•	Solar Charge Controller			
Туре	MPPT/PWM			
Max.PV Open Circuit Array Volatge	132VDC			
Charge Algorithm	3-stage Bulk / Acceptance / Float Plus Equalize			
LCD Display	Backlit, Alphanumeric Display showing battery voltage, DC amperage, Cumulative KWH hours			
	<u>OUTPUT</u>			
Output Volt Amp Capacity (VA)	2500			
Output Watt Capacity (watts)	2000W			
DC System Voltage (VDC)	72V			
Load Capacity	>110% faulty after 300ms			
Phases	1Phase - 3 Wire (L.N.E)			
Output AC waveform	Pure Sine Wave			
Efficiency	> 88%			
	GENERAL			
	UPS ON (Yellow), Battery Low (Red), Mains ON (Green), Charging			
LCD / LEDs Indications	(Green), Overload(Red)			
Alarms	Audible alarm indicates power failure and overload conditions			
	1)Switch control off / on power status			
Switches	2)Switch for mains input voltage range			
	3)Switch to select the maximum charging voltage			
Protection	> 300% Load (with manual reset function)			
Cooling Method	Forced air cooled			
To a section Time	Battery to line mode: 300 milliseconds / Line to battery mode: 300			
Transfer Time	milliseconds			
Housing Material	Powder coated / painted MS			
	ENVIRONMENTAL			
Operating Temperature Range	0°C to 50°C			
Relative Humidity	95% (non-condensing)			
Degree of Protection	IP 20			
	BATTERY			
No of Battery 6				
Battery Charging Profile(Boost /Foat)	Suitable according to Battery type (eg: VRLA/SMF/Wet Lead Acid			

Olympus Power Pvt.Ltd. <u>Technical Features</u>



SO2572

<u>802572</u>				
Max Charging Current(when battery is fully discharge)	10A ±2amp			
SPECIAL FEATURES				
Cold Start (startup in battery mode during a power failure)	Cold-start operation supported			
Charge End Voltage	Grid charging stop when battery reaches 13.8V ±0.2V and transfer to backup mode (per battery)			
Grid Recharge Voltage	Grid charging starts when battery reaches 11V ±0.2V and transfer to grid (per battery)			
	CERTIFICATIONS			
Quality Certifications	ISO 9001:2008			
	WARRANTY			
Product Warranty Period	1 - year limited warranty			

We are committed to continuous development of our products, the specification are subject to change without notice.